ELIUM Player Demo WebApp User Guide

ON/OFF – standby on/off

In Start view (Welcome) / during URL (channel) playback:

OK – open Channellist (stop playback)

MENU – open Main Menu (stop playback)

RED – open Video-On-Demand Movies Demo View (stop playback)

Green – open NetShare MovieBrowser (FileBrowser) (stop playback)

Yellow – open Channel Logos Demo View (stop playback)

Green – open Custom URL Editor (stop playback)

during FILE playback:

EXIT – return to NetShare MovieBrowser (FileBrowser) (stop playback)

MENU – open Main Menu (stop playback)

PLAY/PAUSE – pause or resume playing

REW.BACK (<<) – seek 30 sec backwards

REW.FWD (>>) – seek 30 sec forwards

GO PREV (|<) – seek to file start

MUTE – mute or unmute audio

In Channellist:

EXIT – return to Start view (Welcome)

LEFT/RIGHT/UP/DOWN – navigation

OK – start URL (channel) playback for selected channel

In Main Menu:

EXIT – return to Start view (Welcome)

OK – select menu item

LEFT / RIGHT – navigation

In Network / Netshare SubMenu:

EXIT – return to Main Menu

UP/DOWN – navigation

0..9 – insert text (data) to controls; press the same button with the short time interval for the next character on it

MODE – set uppercase or lowercase characters in respective controls

LEFT – remove last characters for text edit controls / prev for select controls

RIGHT – end same button characters change for text edit controls / next for select controls

OK – confirm (press button) for button controls

In Playlist SubMenu:

EXIT – **save changes (delete selected)** and return to Main Menu

LEFT/RIGHT/UP/DOWN – navigation

OK – select channel for delete

EPG – invert selected channels

LAST – discard all selections

In NetShare MovieBrowser (FileBrowser):

EXIT – return to Start view (Welcome)

LEFT/RIGHT/UP/DOWN – navigation

OK – start FILE playback when file item selected / go into directory when directory item selected / go back from directory (return to the upper directory) when 'Go Back' directory item selected

MODE – select next MovieBrowser source location
(→ NetShare network shared folder → USB → SDCARD →)

In Custom URL Editor:

EXIT – return to Start view (Welcome)

UP/DOWN – navigation

0..9 – insert text (data) to controls; press the same button with the short time interval for the next character on it

MODE – set uppercase or lowercase characters in respective controls

LEFT – remove last characters for text edit controls / prev for select controls

RIGHT – end same button characters change for text edit controls / next for select controls

OK – confirm (press button) for 'PLAY' button control: start URL (channel) playback and save URL as a channel if the respective option selected

In Video-On-Demand Movies / Channel Logos Demo Views:

EXIT – return to Start view (Welcome)

LEFT/RIGHT/UP/DOWN – navigation